


# SMAEL<sup>®</sup>

## ELECTRONIC WATCH OPERATION INSTRUCTION




### A.Features:

- ◆ 12 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- ◆ 12/24H format selectable, Auto Calendar.
- ◆ Daily Alarm and Chime hourly
- ◆ 1/100 second Chronograph with split functions.
- ◆ EL backlight

### B.Operational Manual:

- ◆ Press B key to convert MODE:



### C.Chronograph functions:

- ◆ In normal mode press B key once Chronograph, Press C to start, Press C again to stop, Press D to zero, Press B to normal mode!

### D.Alarm & Chime ON/OFF:


- ◆ In normal mode, press B key twice to enter Alarm mode, then press C to ON/OFF "ALM"/"SIG" function. In normal mode, press C and D ON/OFF "ALM" / "SIG".
- ◆ In normal mode, press B key twice to enter Alarm mode, then press D key once, "Hour" flashing, press D key once again, "Minute" flashing, press C key, can adjust "Hour" and "Minute" respectively, press B key to normal mode.

### E.Time & date setting:

- ◆ In normal mode, press B three times enter into setting mode and the "Seconds" flashing, press D key, "Minute", "Hour", "Date", "Month", "Week" Flashing successively. Press C key can adjust: Time, Minute, Month, Date, Week. Press B key to normal mode.
- ◆ Press B to the clock mode.

### F.Adjust Hands Time:

1. Pull-out crown to stop the second hands stop.
2. Rotate crown to settle time.
3. After settle the time, push the crown firmly to the normal location.



You can wear the watch when bathing and washing car.  
But never push button in the water.